
Service Service Service




16601A2

00S/00F/00W/20S/20F/20W 22S/22F/22W/51S/51F/51W

Service Manual






DocumentationTechnique Service Dokumentation Documentazione di Servizio Huolte-Ohje Manual de Servicio Manual de Serviçio



Subject to modification



T094		4822 142 40256	R411	27 Ω - 0.125 W	4822 111 30408
S100 U100 S102	Loudspeaker	4822 240 20183 4822 150 10116 4822 157 50849			
SK101 ÷ 112 SK6 U882		4822 277 20228 4822 276 10679 4822 276 20203	R856 ÷ 867 R882 R884 R886	100 kΩ 4.7 kΩ 4.7 kΩ 4.7 kΩ	4822 105 90006 4822 105 10331 4822 105 10331 4822 105 10331
			-11-		
			C101	4.7 nF - 2 kV	4822 121 20186

